

SCAG[®]

GIANT-VAC[®]

OPERATOR'S MANUAL


EXTREME PRO Leaf Blower

Model: LBXP17-GX390



Congratulations on owning a Scag Giant-Vac blower! This manual contains the operating instructions and safety information for your Scag Giant-Vac blower. Reading this manual can provide you with assistance in maintenance and adjustment procedures to keep your blower performing to maximum efficiency. The specific models that this book covers are listed on the inside cover. Before operating your blower, please read all the information enclosed.

EXTREME PRO BLOWER ASSEMBLY



Section 6

EXTREME PRO BLOWER ASSEMBLY

Ref. No.	Part No.	Description
1	462619	Handle, Upper w/Grip (incl. #2)
2	485074	Grip, 1" x 25-1/2"
3	483533	Knob
4	484935	Control Cable, Air Direction (incl. #3)
5	04003-15	Bolt, Carriage 5/16-18 x 1-3/4"
6	04001-04	Bolt, Hex Head 1/4-20 x 1-1/2"
7	462632	Mounting Bracket, Control Plate w/Decal
8	04003-43	Bolt, Carriage #10-24 x 1/2"
9	04021-26	Locknut, #10-24
10	04019-02	Nut, Serrated Flange 1/4-20
11	485006	Cable, Throttle Control
12	04021-08	Nut, Elastic Stop 1/4-20
13	04001-03	Bolt, Hex Head 1/4-20 x 2"
14	462609	Handle Bar Cover w/Decal
15	04017-19	Bolt, Hex Head Serrated Flange 5/16-18 x 1-1/2"
16	04117-01	Nut, Flange Elastic Stop 5/16-18
17	04019-03	Nut, Serrated Flange 5/16-18
18	484875	Handle, Lower - LBX
19	44200	Guide, Pull Rope
20	484840	Knob, 3/8-16 Thread
21	484843	Mount, Vibration
22	484764	Spring, Air Discharge Door
23	04020-04	Nut, 3/8-16 UNC
24	44202	Rod, Forward Air Control
25	481284	Bumper, Rubber
26	426362	Bracket, Limiter Plate
27	04003-15	Bolt, Carriage 5/16-18 x 1-3/4"
28	485071	Wheel Assembly, 13 x 5-6
	485124	Tire
	485123	Rim w/Valve
	485010	Bearing
29	04050-09	Retaining Ring, .625 Ext.
30	452497	Door Weldment, Side Discharge Control
31	426163	Pivot Bracket, Side Discharge
32	483453-24	Bearing, .250 ID
33	04017-16	Bolt, Serrated Flange 5/16-18
34	483453-25	Bearing, .375 ID
35	426211	Door, Forward Air Control
36	04003-07	Bolt, Carriage 1/4-20 x 1/2"
37	426350	Caster Bracket, Extreme
38	04001-119	Bolt, Hex Head 5/8-11 x 5-1/2"
39	04021-13	Nut, Elastic Stop 5/8-11
40	04117-02	Nut, Flange Elastic Stop 3/8-16
41	484844	Wheel Assembly, 4.10 x 3.5-4
	485008	Tire
	485009	Rim w/Valve
	485010	Bearing
42	462608	Baffle Assembly, Extreme Pro w/Decal
43	43952	Spacer, Wheel
44	04001-175	Bolt, Hex Head 5/16-18 x 1-1/2" Grade 8
45	04030-03	Lockwasher, 5/16"
46	04063-08	Key, 1/4 x 1/4 x 2"
47	485058	Tapered Hub, P2 - 1" Bore
48	452504	Impeller Weldment, 17" Extreme Pro
49	04001-205	Bolt, Hex Head 5/16-24 x 2-1/2"
50	462631	Housing Weldment, Extreme Pro w/Decals
51	04001-12	Bolt, Hex Head 5/16-18 x 1-3/4"
52	04040-15	Flatwasher, 5/16-.375 x .875 x .083
53	484953	Engine, Honda GX390 (not available through Scag Giant-Vac)
54	43927	Spacer, Engine