




ILLUSTRATED PARTS MANUAL




Model RS-S Ride-On Attachment

**THIS MANUAL CONTAINS THE ILLUSTRATED PARTS LIST FOR MODELS:
RS-S with a serial number of E3500001 to E3599999**

Table of Contents

RS-S ASSEMBLY	2
RS-S DECALS.....	4

RS-S ASSEMBLY



RS-S ASSEMBLY

Ref. No.	Part Number	Description	Ref. No.	Part Number	Description
1	04003-23	Bolt, Carriage 3/8-16 x 1"	18	04021-07	Nut, Elastic Stop 1/2-13
2	452012	Latch Weldment	19	04001-37	Bolt, Hex Head 1/2-13 x 5-1/2"
3	483779	Spring, Latch	20	48307	Caster Wheel Assy.
4	04001-46	Bolt, Hex Head 3/8-16 x 2-1/4"	21	48314	Decal, Scag Logo
5	04021-09	Nut, Elastic Stop 3/8-16	22	481770	Bearing, Oilite
6	452011	Mounting Bracket Weldment	23	04021-10	Nut, Elastic Stop 5/16-18
7	04001-09	Bolt, Hex Head 5/16-18 x 1"	24	48114-03	Grease Fitting, 45 Degree 1/4-28
8	424853	Mounting Bracket, Sulky	25	481769	Roller Bearing
9	04001-19	Bolt, Hex Head 3/8-16 x 1"	26	43022	Sleeve, Caster Wheel Bearing
10A	452010	Mounting Shaft Weldment	27	481772	Rim Pair, Caster Wheel
10B	452067	Mounting Shaft Weldment	28	481774	Tire Only, Caster Wheel
11	04019-04	Nut, Serrated Flange 3/8-16		481773	Inner Tube Only (not shown)
12	48100-24	Bushing, Bronze	29	481768	Hub Assy.
13	462153	Sulky Weldment (incl. #12, 14, 21)	30	481771	Tapered Nut, 5/16-24
14	483777	Decal, Warning	31	04043-04	Flatwasher, 3/8
15	481657	Bearing	32	04066-02	Quick Pin
16	481025	Seal, 2" O.D. x 1.625" Bore	33	481559	Cap, Grease
17	452000	Yoke Weldment	34	04021-20	Nut, Elastic Stop 1.0"-14

RS-S DECALS

 WARNING	
	
TO AVOID SERIOUS BODILY INJURY: * Do not operate on slopes greater than 20 degrees * Always keep both hands on turning controls * Maximum operator weight not to exceed 230 lbs BEFORE LEAVING THE RIDE-ON ATTACHMENT: * Disengage blade clutch * Position speed control in neutral * Apply Parking Brake * Wait for all movement to stop READ OPERATOR' MANUAL	

SCAG[®]

48314

483777