


SCAG[®]

POWER EQUIPMENT



ILLUSTRATED PARTS MANUAL



Model SW Walk-Behind

THIS MANUAL CONTAINS THE ILLUSTRATED PARTS LIST FOR MODELS:


**SW32-14FS
SW36A-14FS
SW48V-14FS
SW52V-15FS**

**with a serial number of J6000001 to J6099999
with a serial number of J6100001 to J6199999
with a serial number of J6200001 to J6299999
with a serial number of J6300001 to J6399999**

Table of Contents

32" & 36A CUTTER DECKS	2
48V & 52V CUTTER DECKS	4
NOTES.....	6
CASTER ASSEMBLY.....	7
ENGINE DECK	8
HANDLE ASSEMBLY.....	10
SW FUEL SYSTEM	12
INSTRUMENT PANEL.....	14
PEERLESS TRANSMISSION 700-070	15
WIRE HARNESSSES	16
NOTES.....	17
REPLACEMENT DECALS AND INFORMATION PLATES	18

32" & 36A CUTTER DECKS




Section 8

32" & 36A CUTTER DECKS

Ref. No.	Part No.	Description	32	36	Ref. No.	Part No.	Description	32	36
1	461847	Cutter Deck w/Decals	x		45	483215	Idler Pulley, Belt Clutch	x	x
1A	461848	Cutter Deck w/Decals		x	46	481024	Seal, Cutter Spindle	x	x
2	461663	Cutter Spindle Assembly	x	x	47	43297	Spindle Bushing	x	x
3	43312	Spacer, Outside	x	x	48	43296	Spacer, Inside	x	x
5	481022	Bearing, Tapered	x	x	49	481035	Nut, 1.06-18	x	x
6	43644	Spindle Housing	x	x	50	48677	Relief Fitting, Cutter Spindle	x	x
7	04001-154	Bolt, 5/16-18 x 4-3/4"	x	x	51	481025	Seal, Cutter Spindle	x	x
8	43589	Spindle Shaft	x	x	52	484368	Spindle Shield	x	x
9	04001-51	Bolt, 3/8-16 x 3-3/4" Hex Head	x	x	53	04029-04	Wing Nut, 3/8-16 (Small) RH side	x	x
10	04063-08	Key, 1/4 x 1/4 x 2"	x	x	54	48114-04	Grease Fitting	x	x
11	43592	Spacer, Cutter Blade - Small	x	x	55	04021-09	Nut, Hex Elastic Stop 3/8-16	x	x
12	04001-175	Bolt, 5/16-18 x 1-1/2" Hex Head Grade 8	x	x	56	04030-03	Lock Washer, 5/16"	x	x
13	482245	Spring, Chute Return	x	x	57	04003-23	Bolt, Carriage 3/8-16 x 1"	x	x
14	04019-03	Nut 5/16-18 Serrated Flange	x	x	58	423783	Baffle Weldment		x
15	481706	Cutter Blade, 16-1/2"	x		59	483174	Pad, Deck Wear	x	x
	481707	Cutter Blade, 18"		x	60	04003-12	Bolt, Carriage 5/16-18 x 3/4"	x	x
15A	481710	Cutter Blade 16-1/2 Hi-Lift	x		61	04040-04	Flatwasher, 5/16"	x	x
	481711	Cutter Blade, 18 Hi-Lift		x	62	04021-04	Hex Nut, 5/16-18 Center Locknut	x	x
16	04043-06	Flatwasher, 5/8 W	x	x	63	424367	Dust Shield	x	x
17	04001-41	Hex Hd. Bolt, 5/8-11 x 9-1/2"	x	x	64	424661	Heatshield	x	x
18	461023	Caster Assembly	x	x					
19	04017-16	Cpscrw, 5/16-18 x 3/4" Ser. Flg. Hex Head	x	x					
20	461355	Discharge Chute	x						
20A	461356	Discharge Chute		x					
	*462469	CA Discharge Chute		x					
	*425872	Turbo Baffle		x					
21	04021-10	Hex Nut, 5/16-18 Elastic Stop	x	x					
22	04001-09	Hex Hd Bolt, 5/16-18 x 1"	x	x					
23	462392	Belt Cover Assy (Incl. Decal)	x						
23A	462393	Belt Cover Assy (Incl. Decal)		x					
24	04043-04	Flat Washer, 3/8" Special	x	x					
25	04029-03	Wing Nut, 3/8-16	x	x					
26	482744	Pulley	x	x					
27	48926	Tapered Hub	x	x					
28	04001-172	Hex Hd. Bolt, 1/4-20 x 1"	x	x					
29	04020-09	Hex Nut, 5/8-11	x	x					
30	48278	Belt, Blade Drive	x						
30A	48204	Belt, Blade Drive		x					
31	04021-22	Elastic Stop Nut, 5/16-18 Grade 8	x	x					
32	04021-05	Hex Nut, 3/8-16 Center Locknut	x	x					
33	04019-04	Nut, 3/8-16 Serrated Flange	x	x					
34	04004-02	Support, Belt Cover	x	x					
35	04017-36	Cpscrw, 1/2-13 x 1" Ser. Flg. HH	x	x					
36	04117-04	Nut, 1/2-13 Flange El. Stop	x	x					
37	43277	Spacer, J-Hook	x	x					
38	04041-12	Flatwasher, 3/8 x 1-1/2 x 16 GA	x	x					
39	04021-09	Elastic Stop Nut, 3/8-16	x	x					
40	43681	Idler Pivot	x	x					
41	461841	Idler Arm Assy. (Inc. 42)	x	x					
42	48224	Bearing	x	x					
43	04001-62	Cpscrw, 3/8-16 x 3-1/4" Hex Head	x	x					
44	44078	J-Hook	x	x					

* = California Models Only (not shown)

48V & 52V CUTTER DECKS



48V & 52V CUTTER DECKS


Ref. No.	Part No.	Description	48	52
1	461852	Cutter Deck w/Decals	x	
	461855	Cutter Deck w/Decals		x
2	461663	Spindle Assembly	x	x
3	43296	Spacer, Inside	x	x
4	482744	Pulley	x	x
5	481022	Tapered Bearing	x	x
6	43644	Spindle Housing	x	x
7	48114-04	Grease Fitting Str. 5/16"	x	x
8	43589	Spindle Shaft	x	x
9	43682	Idler Pivot	x	x
10	04063-08	Key, 1/4 x 1/4 x 2"	x	x
11	43592	Spacer, Cutter Blade - Small	x	x
12	04001-175	Bolt, 5/16-18 x 1-1/2" Hex Head Gr. 8	x	x
13	04001-154	Bolt, 5/16-18 x 4-3/4" Hex Head	x	x
14	04019-03	Serr. Flange Nut, 5/16-18	x	x
15	481706	Cutter Blade 16-1/2"	x	
	481707	Cutter Blade 18"		x
15A	481710	Cutter Blade 16-1/2 Hi-Lift	x	
	481711	Cutter Blade 18 Hi-Lift		x
16	04043-06	Flatwasher, 5/8" (.688 x 1.75 x .134)	x	x
17	04001-41	Hex Head Bolt, 5/8-11 x 9-1/2"	x	x
18	461023	Caster Assembly	x	x
19	484368	Cap, Spindle	x	x
20	04017-16	Capscrew, 5/16-18 x 3/4"	x	x
21	461844	Discharge Chute 48V	x	
	*462473	CA Discharge Chute, 48V	x	
	*425619	Turbo Baffle, 48V	x	
	461845	Discharge Chute 52V		x
	*462475	CA Discharge Chute, 52V	x	x
	*424211	Turbo Baffle, 52V		x
22	04021-10	Nut, 5/16-18 Elastic Elastic Stop	x	x
23	04001-11	Bolt, 5/16-18 x 1-1/2" Hex Head	x	x
24	462394	Belt Cover (Incl. decals)	x	
	462395	Belt Cover (Incl. decals)	x	x
25	04043-04	Flat Washer, 3/8" Special	x	x
26	04029-03	Wing Nut, 3/8-16 (Large)	x	x
27	04110-03	U-Nut, 3/8-16	x	x
28	48926	Tapered Hub		x
29	04001-172	Bolt, 1/4-20 x 1" Hex Head Grade 8	x	x
30	04020-09	Nut, 5/8-11 Hex	x	x
31	482748	Pulley, Double		x
32	48087	Belt, RH Blade Drive	x	
	48285	Belt, RH Blade Drive		x
33	48089	Belt, Blade Drive	x	
	483518	Belt, Blade Drive		x
34	04021-05	Nut, 3/8-16, Nut Centerlock	x	x
35	04019-04	Nut, 3/8-16, Serrated Flange	x	x
36	04021-09	Nut, 3/8-16 Elastic Stop	x	x
37	04004-02	Bolt, 5/16-18 x 1" Hex Head	x	x
38	04001-09	Bolt, 5/16-18 x 1" Hex Head		x
39	04017-36	Cpscrw, 1/2-13 x 1" Ser. Fig. HH	x	x
40	04117-04	Nut, 1/2-13 Flange El. Stop		x
41	04021-04	Hex Nut, 5/16-18 Center Locknut	x	x

Ref. No.	Part No.	Description	48	52
42	44078	J-Hook, 48V	x	
	43028	J-Hook, 52V		x
43	48181	Idler Pulley, "V" Groove	x	x
44	04040-04	Flatwasher, 5/16"	x	x
45	461091	Idler Arm Assy. (Incl. 62)	x	x
46	483176	Pad, Deck Wear	x	x
47	43028	J-Rod, Idler Pulley	x	x
48	43077	Spacer, J-Rod	x	x
49	04041-12	Washer, 3/8 x 1-1/2 x 16 ga.	x	x
50	04001-31	Bolt, 3/8-16 x 2-1/2" Hex Head	x	x
51	481024	Seal, Cutter Spindle	x	x
52	461841	Idler Arm Assy (Includes 62)	x	x
53	43277	Spacer, J-Rod	x	x
54	48677	Relief Fitting, Cutter Spindle	x	x
55	43312	Spacer, Outside, Cutter Spindle	x	x
56	43297	Spindle Bushing	x	x
57	481035	Nut, Cutter Spindle	x	x
58	481625-01	Knob, w/stud	x	x
59	04001-51	Bolt, 3/8-16 x 3-3/4" Hex Head	x	x
60	43681	Idler Pivot	x	x
61	483215	Idler Pulley, Belt Clutch	x	x
62	48224	Bearing	x	x
63	04003-12	Bolt, Carriage 5/16-18 x 3/4"	x	x
64	482295	Guide Roller	x	x
65	45944	Roller Shaft	x	x
66	481025	Seal, Cutter Spindle	x	x
67	483378	Spring, Chute Return	x	x
68	424839	Baffle Weldment 48V	x	
	424840	Baffle Weldment 52V		x
69	04001-62	Bolt, 3/8-16 x 3-1/4" Hex Head	x	x
70	04003-23	Bolt, Carriage 3/8-16 x 1"	x	x
71	424661	Heatshield	x	x
72	04021-22	Nut, Hex Lock 5/16-18	x	x
73	04030-03	Lock Washer 5/16"	x	x
74	424367	Dust Shield	x	x
75	04001-22	Bolt, 3/8-16 x 2-3/4" Hex Head	x	x

* = California Models Only (not shown)

NOTES


CASTER ASSEMBLY



SW-SWZ2006CSTR

Ref. No.	Part No.	Description
1	04066-01	Quick Pin
2	43037-01	Spacer, Spacer Yoke, 1/2" Long
3	48100-01	Bronze Bearing
4	48114-04	Greasing Fitting
5	46082	Support Assembly (Incl. #3 & #4)
6	45006	Caster Yoke
7	04021-07	Nut, Elastic Stop 1/2-13
8	43022	Sleeve, Caster Wheel Bearing
9	04001-37	Bolt, Hex Head 1/2-13 x 5-1/2"
10	9275	Flat-Free Tire Assy. (Incl. #11, #12, #13)
11	48114-03	Grease Fitting, 45 Degree 1/4-28
12	481770	Retainer, Caster Wheel Bearing
13	481769	Roller Bearing, Caster Wheel

ENGINE DECK




SW2013ED

ENGINE DECK

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	485014	Engine, Kawasaki 14FS (FS481V)	29	04063-19	Key, 1/4 x 1/4 x 3/4"
	485015	Engine, Kawasaki 15FS (FS541V)	30	04041-28	Flat Washer, 7/16" Special
2	48030-09	Cable Clamp	31	04030-05	Lock Washer, 7/16"
3	481580	Transmission, 5-speed (Peerless 700-070, 9 tooth spline)	32A	04102-04	Bolt, 7/16-20 x 2-1/2" Hex Head
4	48231	Neutral Safety Switch	32B	04103-03	Cpsrw, M10-1.5 x55 Metric Hex Hd
5	48122-01	Fibre Washer, thin	33	04001-12	Bolt, 5/16-18 x 1-3/4" Hex Head
5A	48122-02	Fibre Washer, thick	34	04002-06	Bolt, M8-1.25 x 16
6	481581	Coupler, Jackshaft	35	04021-09	Nut, 3/8-16 Elastic Stop
7	48114-05	Grease Fitting, straight 1/4-28	36	04040-15	Flat Washer, 5/16"
8	481582	Jackshaft (fits SW32,36,48 & 52)	37	040001-32	Bolt, Hex Head 3/8-16 x 1-1/4"
9	04063-09	Key, Hi-Pro #9	38	48192	Wheel Assembly (incl. 38A-38B) (fits SW36,48,52)
10	04017-16	Bolt, 5/16-18 X 3/4" Hex Head		48253	Wheel Assembly (Incl. 38C - 38D) (SW32)
11	43085**	Wheel Axle (SW36,48 & 52)	38A	481860	Tire, 13 x 6.50-6, 2-ply (fits SW36,48,52)
	43104**	Wheel Axle (SW 32)	38B	481859	Rim & Bearing Assembly (incl. 39)
12	484620	Muffler - Kawasaki	38C	481861	Tire, 13 x 5.00-6 2-ply (SW32 only)
13	04001-08	Bolt, 5/16-18 X 3/4" Hex Head	38D	481862	Rim Assembly (incl. 39) (SW32 only)
14	422533	Backing Plate	39	481858	Wheel Bearing
15	04030-04	Lock Wshr. 3/8"	40	04042-05	Washer, 1-1/16 x 1-3/4 x 12 ga
16	04019-04	Nut, 3/8-16 Serrated Flange	40A	04041-14	Washer, 1-1/16 x 1-1/2 x 18 ga
17	462285	Engine Deck (fits SW32)	41	04050-08	Retaining Ring, 1" Ext.- "E"
	462286	Engine Deck (fits SW36,48 & 52)	42	48200	Pulley, Wheel Drive
18	424620	Plate, Clutch Bracket	43	43088	Spacer, Wheel Pulley
19	04019-03	Nut, 5/16-18 Serrated Flange	44	48209	Brake Drum
20	04001-51	Bolt, 3/8-16 x 3-3/4" Hex Head	45	04017-19	Bolt, 5/16-18 x 1-1/2" Serrated Flange
21	461397	Electric Clutch (Ogura)	46	04003-03	Bolt, 3/8-16 x 2" Carriage
22	04041-07	Washer, 3/8" (.391 x .938 x .105)	47	04021-10	Nut, 5/16-18 Elastic Stop
23	48197	Pulley, Transmission Input	48	04003-04	Bolt, 5/16-18 x 1" Carriage
24	04063-07	Key, Woodruff #9	49	421370	Anti Rotation Bracket
25	04050-09	Retaining Ring, 5/8" Ext, Basic	50	04031-03	Lock Washer External Tooth
26	48203	Belt, Transmission Drive	51	481716	Rubber Pad, Clutch Stop
27	483208	Idler Pulley, Transmission	52	422534	Plate, Backing
28	481666	Pulley, Traction Drive			

** = Requires welding onto chassis.

HANDLE ASSEMBLY




SW 2011 HA

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	461972	Handle Assembly	46	482645	Pulley, Jackshaft (Inc. 47)
2	421360	Belt Guard	47	04012-04	Setscrew, Hex Socket Knurl
3	04017-27	Capscrew, 3/8-16 x 1" Serr. Flg.			Cup Pt. 5/16-18
4	04041-07	Washer, 3/8" (.391 x .938 x .105)	48	43098	Spacer, Jackshaft Pulley
5	04021-09	Nut, 3/8-16 Elastic Stop	49	48223	Flange, Jackshaft Bearing
6	48755	Spring, Idler	50	48224	Bearing, Jackshaft
7	04001-10	Bolt, 5/16-18 x 1-1/4" Hex Head	51	04050-09	Retaining Ring, 5/8 Ext. Basic
8	04021-10	Nut, 5/16-18 Elastic Stop	52	422279	Shift Lever
9	04017-05	Capscrew, 1/4-20 x 3/4" Hex Head	53	04017-16	Capscrew, 5/16-18 x 3/4" Serr. Flg.
10	44140	Control Rod, Steering	54	04001-17	Bolt, 5/16-18 x 2" Hex Head
11	04062-02	Hair Pin, Small	55	04019-02	Nut, 1/4-20 Serrated Flange
12	04001-23	Bolt, 3/8-16 x 4-1/2" Hex Head	56	481839	Grip, Shift Handle
13	43032	Swivel Joint	57	424113	Bracket, Choke Mounting
14	04062-01	Hair Pin, Large .094 Dia.	58	461163	Shift Lever Extention (incl. 56)
15	45847	Idler Bracket, RH	59	04041-07	Washer, 3/8 (.391x .938 x .105)
15A	45846	Idler Bracket, LH	60	482314	Choke Control
16	43092	Idler Sleeve	61	483161	Plug, Handlebar
17	04001-62	Bolt, 3/8-16 x 3/4" Hex Head	62	04020-14	Nut, 3/8-24 UNF
18	04004-17	Stud, 3/8-16 x 5"	63	04001-53	Bolt, 5/16-18 x 2-1/2"
19	04019-04	Nut, 3/8-16 Serrated Flange	64	482547	Fuel Tank Cap
20	04019-03	Nut, 5/16-18 Serrated Flange			
21	04017-28	Cpscrew, 3/16-18 x 1-1/4" Serr. Flg			
22	43286	Spacer			
23	48028-05	Cable Tie			
24	483160	Steering Lever			
25	04017-17	Capscrew, 5/16-18 x 1" Serr. Flg.			
26	483142	Bushing			
27	04040-15	Washer, 5/16 (.375 x .875 x .083)			
28	483040	Spring, Operator Presence			
29	451915	Operator Presence Lever, LH			
30	451917	Operator Presence Lever, RH			
31	44005	Brake Rod			
32	45092	Brake Lever			
33	45093	Brake Link			
34	42254	Brake Link Plate			
35	04024-01	Nut, 3/8 Push-on			
36	48114-05	Grease Fitting, Straight 1/4-28			
37	04050-01	Retaining Ring, 5/8 Ext. "E"			
38	48210	Brake Band			
39	04001-45	Bolt, 3/8-16 x 2" Hex Head			
40	04031-08	1/4" Internal Tooth Lockwasher			
41	04032-01	Socket Head Capscrew #8-32 x 1/2"			
42	04015-13	Socket Head Capscrew #8-32 x 1/2"			
43	461242	Neutral Latch, RH			
43A	461241	Neutral Latch, LH			
44	48202A	Belt, Wheel Drive			
45	483211	Idler Pulley, Wheel Drive			

SW FUEL SYSTEM




2011 SW EPA Phase 3 Fuel System

SW FUEL SYSTEM

Ref. No.	Part No.	Description
1	462375	Fuel Tank Assembly (incl. #3, 4, 5, 6, 16, 17)
2	484286	Fuel Cap w/ Tether
	484297	Fuel Cap w/Tethered - California Models Only (not shown)
3	484259	Fuel Gauge Assembly (incl. #4)
4	484242	Seal, Fuel Gauge
5	482571	Bushing, .56 Dia. Viton
6	483747	Ball Valve w/Screen
7	48059-01	Clamp, Fuel Hose
8	483617	Fuel Hose, 1/4" ID (order by inch)
9	*	Fuel Filter
10	*	Clamp, Fuel Hose
11	*	Fuel Hose
12	484347	Hose, Vapor Recovery 1/4" (order by inch)
13	04030-03	Lockwasher, 5/16" Spring
14	04001-09	Bolt, Hex Head 5/16-18 x 1"
15	484287	Carbon Canister
16	484285	Grommet, Viton,
17	484333	Fitting, Remote Vent
18	484343-01	Mender, 1/4 x 3/16 w/.02 Hole
19	48030-22	Clamp, 3/8"
20	484345	Hose, Vapor Recovery 3/16" (order by inch)
21	04001-08	Bolt, Hex Head 5/16-18 x 3/4"
22	48059-05	Clamp, Vapor Recovery Hose 3/16"
23	48059-02	Clamp, Fuel Hose 7/32" ID
24	04019-03	Nut, Serrated Flange 5/16-18
25	452176	Bracket, Canister Mounting
26	48136-17	Clamp
27	04003-04	Bolt, Carriage 5/16-18 X 1"
28	484279-01	Tube, Fuel Tank Insert - 4"

* = Available through engine manufacturer only.

INSTRUMENT PANEL




SW2014 IP

Ref. No.	Part No.	Description
1	48717	Switch, Neutral Lock
2	48946	Throttle Control - Kawasaki
3	483957	Engagement Switch, Electric Clutch
4	48609	Key Switch
5	48023	Hour Meter (dealer installed)
6	04003-43	Bolt, Carriage #10-32 x 1/2"
7	04021-26	Nut, #10-32 Elastic Stop
8	482711	Handle Wire Harness, Manual Start
9	462069	Key Chain w/Keys
	483609	Key w/Shroud
NS	48030-09	Clamp, Wire Harness


PEERLESS TRANSMISSION 700-070

FOR REFERENCE ONLY - ORDER PARTS FROM PEERLESS / TECUMSEH




Ref. No.	Part No.	Description	REF. NO.	PART NO.	PART DESCRIPTION
1	772083A	Case, Transmisson	50	778125	Spur Rear (35 teeth)
2	780086A	Needle Bearing Grease Spec	51	778239A	Spur Gear (32 teeth-steel)
2A	780142	Needle Bearing	52	778124A	Spur Gear (30 teeth)
3	770061A	Case, Transmission	53	778123A	Spur Gear (25 teeth)
8	792089A	Shift Key	56	778145	Spur Gear (12 teeth-steel)
9	784266	Shift Collar	57	778151	Spur Gear (15 teeth)
10	784376	Shift Rod & Fork	58	778240	Spur Gear (18 teeth-steel)
11	778154	Bevel Gear (42 teeth)	59	778126A	Spur Gear (20 teeth)
12	778176	Bevel Pinion (14 teeth-steel)	60	778127A	Spur Gear (25 teeth)
20	792077	Steel Ball, 5/16" dia.	65	780139	Washer
21	792078	Set Screw, 3/8-16 x 3/8"	66	776135	Input Shaft (3-11/16" long)
22	792079	Spring	67	776402	Shifter & Brake Shaft
24	780071	Thrust Bearing	71	788069	Square Cut Ring
25	792073	Screw, 1/4-20 x 1-1/4" (6)	72	792074	Threaded Plug (Shipping only, not used)
27	792035	Retaining Ring	81	786081	Roller Chain (No. 41 chain, 24 links)
28	788040	Retaining Ring	82	786082	Sprocket (9 teeth)
29	780072	Washer (6)	83	786083	Sprocket (18 teeth)
30	780108	Washer (5)	90	788067B	Grease (32 oz. bottle Bentonite grease)
32	792001	"O" Ring	150	510334	Gasket Eliminator (Loctite #515)
34	780105A	Flanged Bushing	178	*	Coupling (See page 26-27 for part number)
49	778146A	Spur Gear (37 teeth)	179	*	Connector Shaft (See page 26-27 for part number)

WIRE HARNESSES



HANDLE WIRE HARNESS PART NO. 482711



SW2007WH482711

NOTES


REPLACEMENT DECALS AND INFORMATION PLATES




1



2




3




4



10



6



7




8



9

REPLACEMENT DECALS AND INFORMATION PLATES

Ref. No.	Part No.	Description
1	483405	Decal, Discharge Chute
2	48314	Decal, Scag Logo
3	483407	Decal, Danger-Spinning Blades
4	483406	Decal, Warning-Rotating Blades
5	481971	Decal, Heavy Duty Commercial
6	48332	Decal, Shift Index
7	483441	Decal, Instrument Panel - Rear
8	48404	Decal, Metalcraft - Made in USA
9	483404	Decal, Sully Attachment
10	483402	Decal, Belt Cover
11	481483	Decal, Instrument Panel - Front
12	482816	Decal, Height of Cut
13	48315	Decal, 32
	482297	Decal, 36 Advantage
14	483199	Decal, 48 Velocity Plus
	483200	Decal, 52 Velocity Plus
**	461986	Spanish Decal Kit, Walk-Behinds (Not Shown)
**	483900	Decal, Warning Spark Arrest (Not Shown) - California Models Only



11

482816 CUTTING HEIGHT ADJUSTMENT							
DECK MOUNTING HOLE POSITION							
NUMBER OF CASTER SPACERS (BELOW SUPPORT)							
NUMBER OF SPACERS ABOVE CUTTER BLADES							
	0	1	2	3	4	5	
TOP	0	-	-	2-3/8	2-1/8	1-7/8	1-5/8
MIDDLE	0	-	-	2-5/8	2-3/8	2-1/8	1-7/8
MIDDLE	1	-	-	2-3/4	2-1/2	2-1/4	2
BOTTOM	2	-	-	-	-	2-7/8	2-5/8
BOTTOM	3	-	4	3-3/4	3-1/2	3-1/4	3
BOTTOM	4	4-3/8	4-1/8	3-7/8	3-5/8	3-3/8	3-1/8

12



13



14



5